

# Contents

<b>1.0 Introduction .....</b>	<b>6</b>
1.1 About this Guide .....	6
1.2 Materials for Busbars .....	6
1.2.1 Material Requirements .....	6
1.2.2 Material Choice .....	7
1.2.2.1 High Conductivity .....	7
1.2.2.1.1 Effect of Temperature on Conductivity .....	9
1.2.2.1.2 Effect of Cold Work on Conductivity .....	9
1.2.2.2 Mechanical Strength .....	9
1.2.2.2.1 Tensile Strength .....	10
1.2.2.2.2 Proof Strength .....	10
1.2.2.2.3 Hardness .....	11
1.2.2.2.4 Resistance to Softening .....	11
1.2.2.2.5 Creep Resistance .....	11
1.2.2.2.6 Fatigue Resistance .....	12
1.2.2.2.7 Bending and Forming .....	13
1.2.2.3 Connectivity .....	13
1.2.2.4 Maintenance .....	13
1.2.3 Types of High Conductivity Copper Available .....	14
1.2.3.1 Tough Pitch Copper, CW004A and CW005A (C101 and C102) .....	14
1.2.3.2 Oxygen-free High Conductivity Copper, CW008A (C103) .....	14
1.2.4 Available Forms .....	14
<b>2.0 Current-Carrying Capacity of Busbars .....</b>	<b>15</b>
2.1 Design Philosophy .....	15
2.2 Calculation of Maximum Current-Carrying Capacity .....	15
2.2.1 Methods of Heat Loss .....	15
2.2.1.1 Convection – Natural Air Cooling .....	16
2.2.1.2 Convection Heat Loss – Forced Air Cooling .....	17
2.2.1.3 Radiation .....	18
2.2.2 Heat Generated by a Conductor .....	21
2.2.2.1 Alternating Current Effects – the Factor $S$ .....	22
2.2.2.1.1 Skin Effect and Skin Depth .....	24
2.2.2.1.2 Proximity Factor, $S_p$ .....	27
2.3 Conclusion .....	27
2A Shape and Proximity Factors for Typical Configurations .....	28
2A.1 Skin and Proximity Factors for Common Busbar Shapes .....	28
2A.1.1 Single Solid Rods .....	28
2A.1.1.1 Shape Factor for Single Solid Rods .....	28
2A.1.1.2 Proximity Factor for Single Solid Rods .....	29
2A.1.2 Single Tubes .....	34
2A.1.2.1 Shape Factors for Single Tubes .....	34
2A.1.2.2 Proximity Factors for Tubes .....	37
2A.1.3 Single Rectangular Sections .....	42
2A.1.3.1 Shape Factor for Rectangular Bars .....	42
2A.1.3.2 Approximate Portmanteau Formula for Single Bars .....	45
2A.1.4 Parallel Bars .....	45
2A.1.4.1 Proximity Factor – Anti-parallel Currents .....	45
2A.1.4.2 Proximity Factor – Parallel Currents .....	47
2A.1.5 Three-phase Configurations .....	49
2A.1.5.1 Linear Plots .....	49
2A.1.5.2 Logarithmic Plots .....	53
<b>3.0 Life Cycle Costing .....</b>	<b>56</b>
3.1 Introduction .....	56
3.1.1 The Future Value of Money – Net Present Value .....	56
3.1.1.1 Monthly Payments .....	59
3.1.2 Loading .....	60
3.1.3 Lifetime .....	60
3.1.4 Sensitivity Analysis .....	60
3.2 Application to an Electrical Installation .....	60
3.2.1 Installation Design .....	61
3.2.2 Installation Costs .....	61
3.2.3 Recurring Costs .....	61
3.2.3.1 Maintenance Costs .....	61
3.2.3.2 Energy .....	61
3.2.4 End of Life Costs .....	68
3.3 Conclusion .....	68
<b>4.0 Short-Circuit Effects .....</b>	<b>69</b>
4.1 Introduction .....	69
4.2 Short-Circuit Heating of Bars .....	69
4.3 Electromagnetic Stresses .....	70
4.3.1 Estimating the Forces Between Parallel Sets of Bars .....	72
4.3.1.1 Round Bars .....	72
4.3.1.1.1 Triangular Array .....	73
4.3.1.1.2 In-Line Array .....	74
4.3.1.2 Bars of Rectangular Section .....	74
4.4 Mounting Arrangements .....	76
4.4.1 Maximum Permissible Stress .....	76
4.4.1.1 Moment of Inertia .....	77
4.4.2 Deflection .....	78
4.4.3 Natural Frequency .....	78
<b>5.0 Busbar Profiles .....</b>	<b>79</b>
5.1 Introduction .....	79
5.2 Reasons for Using Profiles .....	79
5.2.1 Skin Effect Reduction .....	79
5.2.2 Weight and Cost Saving .....	79
5.2.3 Integrated Fixings and Mountings .....	80
5.2.4 Retention of Intellectual Integrity .....	80
5.3 Economics of Profiles .....	80
5.4 Practical Profiles .....	80
5.4.1 Manufacturing Process .....	80
5.4.1.1 EN 13605 .....	80
5.4.1.1.1 Straightness, Flatness and Twist .....	82
5.4.2 Design for Manufacturing .....	84
5.4.2.1 Wall Thickness .....	84
5.4.2.2 Avoid Sharp Corners .....	84
5.4.2.3 Symmetry .....	84
5.4.2.4 Be Compact .....	85
5.4.2.5 Avoid Deep Narrow Channels .....	85
5.4.2.6 Avoid Hollow Chambers .....	85
5.4.3 Functional Design .....	85

5.5	Electrical Design Considerations .....	85
5.5.1	Skin Effect .....	85
5.5.2	Thermal Dissipation .....	86
5.5.3	Jointing and Mounting .....	87
5.5.4	Short Circuit Performance - Moment of Inertia .....	88
5.6	Calculation of Moment of Inertia of Complex Sections .....	88
<b>6.0</b>	<b>Jointing of Copper Busbars.....</b>	<b>90</b>
6.1	Introduction .....	90
6.2	Busbar Jointing Methods .....	90
6.3	Joint Resistance .....	91
6.3.1	Streamline Effect .....	92
6.3.2	Contact Resistance .....	94
6.3.2.1	Condition of Contact Surfaces .....	94
6.3.2.2	Effect of Pressure on Contact Resistance .....	94
6.4	Bolting Arrangements .....	98
6.4.1	Joint Efficiency .....	99
6.5	Clamped Joints .....	101
6.6	Degradation Mechanisms .....	101
6.6.1	Oxidation .....	101
6.6.2	Corrosion .....	102
6.6.3	Fretting .....	102
6.6.4	Creep and Stress Relaxation .....	102
6.6.5	Thermal Expansion .....	102
6.7	Conclusion .....	102
<b>Annex: Coatings.....</b>	<b>103</b>	
A1.0	Introduction .....	103
A2.0	Reasons for Coating .....	103
A2.1	Coating to Provide Electrical Insulation .....	103
A2.2	Coating to Inhibit Corrosion .....	103
A2.2.1	Metal Coatings .....	103
A2.2.2	Non-Metallic Coatings .....	103
A2.3	Coating to Increase Current Rating .....	103
A2.4	Coating for Cosmetic Purposes .....	104
A2.5	Coating to Improve Joint Performance .....	104
A3.0	Methods of Coating .....	104
A3.1	Factory Application Methods .....	104
A3.1.1	Extrusion .....	104
A3.1.2	Powder Coating .....	105
A3.2	On-Site Application Methods .....	105
A3.2.1	Heat-Shrinkable Sleeve .....	105
A3.2.2	Painting .....	105
A3.2.2.1	Alkyd Paints .....	105
A3.2.2.2	Two-Part Epoxy .....	105
A4.0	Inspection and Maintenance .....	105

## Tables

Table 1	Properties of Typical Grades of Copper and Aluminium	7
Table 2	Properties of 100% IACS Copper .....	7
Table 3	Implied Properties of 100% IACS Copper .....	8
Table 4	Comparison of Creep Properties of HC Copper and Aluminium .....	12
Table 5	Comparison of Fatigue Properties of HC Copper and Aluminium .....	12
Table 6	Minimum Bend Radius of HC Copper .....	13
Table 7	Self-extinguishing Arcs in Copper and Aluminium Busbars .....	13
Table 8	Discount Factors for Various Discount Rates .....	57
Table 9	Maximum Working Current for a Range of Busbar Sizes .....	62
Table 10	Resistance and Power Loss at 500 Amps .....	62
Table 11	Energy Cost Per Metre for Various Widths of Copper Bars at 500 A Load .....	63
Table 12	Present Value (€) per Metre of Bar .....	67
Table 13	Power Factor and Peak Current .....	71
Table 14	Tolerances for Dimensions $b$ and $h$ for $b_{max}$ or $h_{max} < 20:1$ .....	82
Table 15	Tolerances for Dimensions $b$ and $h$ for $b_{max}$ or $h_{max} \geq 20:1$ .....	82
Table 16	Thickness Tolerances .....	82
Table 17	Coefficient for Twist Tolerance .....	84
Table 18	Maximum Sizes of Profile According to Two Manufacturers .....	84
Table 19	Nut Factors for Different States of Lubrication .....	96
Table 20	Proof Strength and Coefficient of Thermal Expansion for Copper and Typical Bolt Materials .....	96
Table 21	Typical Thread Characteristics .....	97
Table 22	Typical Busbar Bolting Arrangements .....	99

## Figures

Figure 1	Effect of small concentrations of impurities on the resistivity of copper .....	8
Figure 2	Effect of cold rolling on mechanical properties and hardness of high conductivity copper strips .....	10
Figure 3	Typical creep properties of commercially pure copper and aluminium .....	12
Figure 4	Heat dissipation by convection from a vertical surface for various temperature rises above ambient .....	16
Figure 5	Convection loss from typical bar sections .....	17
Figure 6	Heat dissipation by radiation from a surface assuming relative emissivity of 0.5 and surroundings at 30°C .....	18
Figure 7	Radiation loss from typical bar sections .....	19
Figure 8	Convection and radiation losses at various temperatures .....	20
Figure 9	Total heat losses for a single bar of various heights against temperature rise .....	20
Figure 10	Total heat losses for each bar of a parallel pair of various heights against temperature rise .....	21

Figure 11	Parameter $p$ versus cross-sectional area in $\text{mm}^2$ for typical copper at $80^\circ\text{C}$ .....	23	Figure 42	Total cost per metre against current density for a range of operation times.....	66
Figure 12	Resistivity of typical HC copper (101.5% IACS) as a function of temperature.....	25	Figure 43	Estimated working temperature versus width of bar (mm) for 500 A load.....	66
Figure 13	Skin depth of typical HC copper (101.5% IACS) at 50 Hz, 60 Hz, 400 Hz as a function of temperature.....	25	Figure 44	Cost per metre (€) against bar width for a) 20 000 hours operation without discount and b) 2000 hours per year for 10 years at 5% discount.....	67
Figure 14	dc resistance of typical HC Copper (101.5% IACS) versus area at $20^\circ\text{C}$ and $80^\circ\text{C}$ .....	26	Figure 45	Short-circuit current waveform.....	71
Figure 15	Plots of shape factor versus $\gamma$ .....	29	Figure 46	Three phase system with spacings $D$ (mm), (a) triangular array (b) inline array.....	73
Figure 16	Factor $A$ for round bars as a function of $\gamma$ .....	30	Figure 47	Factor $K$ for calculating the force between two bars of rectangular section.....	75
Figure 17	Proximity factor, $Sp$ , for single phase systems with parallel round bars.....	31	Figure 48	Form factor $K_p$ , (a) low values of $a/b$ (long sides facing each other) (b) high values of $a/b$ .....	75
Figure 18	Mean proximity factors for flat arrangement of round bars carrying balanced three phase currents.....	32	Figure 49	Typical copper profiles.....	79
Figure 19	Mean proximity factors for delta arrangement of round bars carrying balanced three phase currents.....	33	Figure 50	A non-typical profile indicating the dimensions used in the standard.....	81
Figure 20	Shape factor for tubes.....	35	Figure 51	Measurement of straightness.....	83
Figure 21	Shape factor for tubes with low values of shape factor.....	35	Figure 52	Measurement of flatness.....	83
Figure 22	Shape factor for tubes.....	36	Figure 53	Measurement of twist.....	83
Figure 23	The shape factor computed from the Bessel function formula using $\sqrt{f/r_{dc}}$ as the frequency parameter.....	36	Figure 54	Profile cross-section showing mounting lugs and slots for bolt-head.....	85
Figure 24	Shape factor as a function of the ratio, $g = \frac{\text{wall thickness } t}{\text{skin depth } \delta}$ .....	37	Figure 55	$R_{ac}/R_{dc}$ as a function of the parameter $\sqrt{f}/R_{dc}$ with $f$ in Hz and $R_{dc}$ in $\mu\Omega/\text{m}$ .....	86
Figure 25	Factor $A$ versus $\beta = t/a$ for values of $g = t/\delta$ .....	38	Figure 56	Thermal image of two profiles under load.....	87
Figure 26	Proximity factor for single phase tubes as function of the factor $A$ for values of $\eta = s/2a = s/d$ .....	38	Figure 57	Hole-free joints.....	87
Figure 27	Proximity factor for single phase tubes.....	39	Figure 58	Calculation of moment of inertia of a complex shape.....	88
Figure 28	Factor $A$ for proximity loss factor as a function of $g = t/\delta$ for various values of $\beta = t/a$ .....	40	Figure 59	Parameters used in the calculation of moment of inertia of each element.....	89
Figure 29	Proximity factor, $Sp$ , for round bars at various spacings designated by $\eta$ .....	41	Figure 60	A typical bolted joint.....	90
Figure 30	$R_{ac}/R_{dc}$ as a function of the parameter $\sqrt{f}/R_{dc}$ .....	43	Figure 61	A simple clamped joint.....	90
Figure 31	$R_{ac}/R_{dc}$ as a function of the parameter $\sqrt{f}/R_{dc}$ .....	43	Figure 62	A riveted joint.....	91
Figure 32	Shape factor, $R_{ac}/R_{dc}$ , as a function of the parameter $\sqrt{f}/R_{dc}$ .....	44	Figure 63	A soldered joint.....	91
Figure 33	Shape factor versus $2b/\delta$ for various values of $b/a$ .....	44	Figure 64	A welded joint.....	91
Figure 34	Plots of the shape ratio $\frac{R_{ac}}{R_{dc}}$ versus the ratio $\frac{s}{a}$ for various values of $\sqrt{\frac{f}{R_{dc}}}$ for anti-parallel currents.....	47	Figure 65	An overlapped joint.....	91
Figure 35	Shape factor $S = \frac{R_{ac}}{R_{dc}}$ as a function of the separation $s$ for various values of $\sqrt{\frac{f}{R_{dc}}}$ with $R_{dc}$ in $\mu\Omega/\text{m}$ and $f$ in Hz.....	49	Figure 66	Streamline effect in overlapped joints.....	92
Figure 36	Linear plots of $R_{ac}/R_{dc}$ versus $p$ where $p \approx 1.5853 \sqrt{\frac{f}{R_{dc}}}$ with $R_{dc}$ in $\mu\Omega/\text{m}$ and $f$ in Hz.....	52	Figure 67	Bolt placement in overlapped joints.....	93
Figure 37	Quasi logarithmic plots of $R_{ac}/R_{dc}$ versus $p$ where $p \approx 1.5853 \sqrt{\frac{f}{R_{dc}}}$ with $R_{dc}$ in $\mu\Omega/\text{m}$ and $f$ in Hz.....	55	Figure 68	Overlap joint between bars with angled ends.....	93
Figure 38	Power loss versus width for 6.3 mm thick copper bars.....	63	Figure 69	The effect of pressure on the contact resistance of a joint.....	95
Figure 39	Cost of energy loss per metre versus width for 6.3 mm thick copper bars.....	64	Figure 70	Possible bolting techniques for copper busbars.....	98
Figure 40	Total cost per metre versus bar width for 5000 hours operation at 500 A.....	64	Figure 71	Joint with a longitudinal slot.....	98
Figure 41	Total cost per metre of bar versus bar width for a range of operating times.....	65			

**Disclaimer**

While this publication has been prepared with care, Copper Development Association, European Copper Institute and other contributors provide no warranty with regards to the content and shall not be liable for any direct, incidental or consequential damages that may result from the use of the information or the data contained.

Copyright© Copper Development Association and European Copper Institute.